TRANSPORT RESTRAINT EQUIPMENT



BEAVER TRUCK WINCHES

TRUCK WINCH GUIDELINES

- > Keep it tight not loose
- Make sure gear teeth are in good working order
- > Make certain appropriate winch is used
- ➤ If you are using a Clip-on Winch ensure the arms are straight not bent
- When in use, ensure that at least 3 loops of webbing remain on winch drum



BEAVER MARK VI CLIP-ON TRUCK WINCHES

Complies to AS/NZS 4380

Code	Description	Hook Type	Width mm	Length m	LC (Kg)	Weight (Kg)	UOM
342109-9A	Clip-on winch c/w 9m strap	Hook & Keeper	50	9	2500	7.45	Each
342109-12A	Clip-on winch c/w 12m strap	Hook & Keeper	50	12	2500	7.85	Each



BEAVER MARK VI SLIDE-ON TRUCK WINCHES

Complies to AS/NZS 4380

Code	Description	Hook Type	Width mm	Length m	LC (Kg)	Weight (Kg)	UOM
342009-9	Slide-on winch c/w 9m strap	Hook & Keeper	50	9	2500	10.25	Each

Compatible with Beaver's Reversible Ratchet Winch Bar (342420)





- · Winches shall not be loaded in excess of lashing capacity.
- A minimum of two layers of polyester webbing must be wound around the winch drum when tensioning.